



Specifications

MEDICI pro strada

STEELWORK

Slotted steering column and bottom bracket are Italian threaded. All bridges and supports are separately reinforced and stiffened.

Frame & ForkColumbus double butted SP on frames 59 cm & larger, SL on 58 cm & smaller
Seat & Chain StaysSpaced to accept narrow spaced 7-speed or conventional 6-speed freewheel. 5-speed design available on special order at no additional cost.
LugsRexart investment cast
Bottom Bracket HangerCinelli investment cast
Fork CrownHaden investment cast
DropoutsRexart slotted, investment cast

COMPONENTS

All Italian threaded except as noted.

HeadsetCampagnolo SUPER RECORD
BrakesCampagnolo SUPER RECORD (short reach)—recessed with yellow cable housing
Bottom BracketCampagnolo Nuovo Record
CrankCampagnolo SUPER RECORD 170 mm to 59 cm 175 mm over 59 cm
ChainringsCampagnolo SUPER RECORD 42/52T to 59 cm 42/53T over 59 cm
DerailleursCampagnolo SUPER RECORD (front & rear) with braze-on option
PedalsCampagnolo Superlight BLACK Road Pedals
HubsCampagnolo SUPER RECORD 36 hole, low flange, BSA thread
Seat PostCampagnolo SUPER RECORD 180 mm long — 27.2 mm diameter
Seat Post BoltHague Stainless Steel
RimsAmbrosio Montreal Durex Gray, Heat Treated, 36 hole
SpokesDT 14 or 15 straight gauge, stainless steel
TiresClement Silk
FreewheelRegina CXS, BSA thread, splined body (7 speed)
ChainRegina CXS (narrow)
Toe ClipsCampagnolo short, normal or long — accord- ing to frame size
Toe StrapsMEDICI, with buttons
Water BottleCobra yellow plastic aerodynamic
Water Bottle CageCobra profile black alloy, SS screws
PumpSilca Frame-fit, color matched to bicycle frame with Campagnolo "blue foot" steel head
SaddleMEDICI Concor
StemMEDICI engraved-black anodized-length according to frame size
HandlebarMEDICI engraved-black anodized, double taped

BRAZE-ON FEATURES

- A. Top Tube brake cable tunnels (3)
- B. Campagnolo Bottom Bracket derailleur cable guides. Placed on top for painted framesets, underneath for plated framesets.
- C. Campagnolo over or under right rear chain stay cable stop (1)
- D. Down Tube and Seat Tube water bottle cage fittings (2)
- E. Down Tube derailleur guides (2)
 - 1. Shift lever bosses, or
 - 2. Fingertip control cable stops
- F. Campagnolo Front Derailleur
- G. Chain Hanger
- H. Pump Peg under Top Tube